


LYNGSON

Mounting instructions





For safety reasons wall plugs aren't delivered. Contact your specialist store for the right type.



MOUNTING INSTRUCTIONS AND TERMS OF GUARANTEE

PROCEDURE 3+4

Fix the brackets with the screws and washers. Regulate the distance to the wall with an Allen key. Be sure that the element is level before screwing. Working pressure max. 6 bars.

TERMS OF GUARANTEE

The manufacturer is responsible for the completeness, the quality and the operation of the heating element as mentioned in our technical instructions. He isn't responsible for defaults caused by non-professional applications, faulty heatloss calculation, non-professional mounting, wrong regulation, etc...

The period of guarantee is 5 years.

Alterations preserved.